

COUCH CONTROL GUIDE









MUSIC CONTROL





PHONE CONTROL





VOLUME CONTROL



AUTOMATIC CHARGING Endurance Peak Only



 \triangle

DO NOT CHARGE WHEN HEADPHONES ARE WET



AUTO POWER ENDURANCE JUMP, DIVE & PEAK ONLY





TOUCH CONTROL





HEADPHONES AUTOMATICALLY ENTER PAIRING MODE

ALL CONTROLS ON RIGHT SIDE



ENDURANCE